AR2800P Water Filter Replacement and Reset Instructions

(PCT/RO Filters)

Step 1: Preparation
- Turn off the water inlet valve.
- Open the faucet to release any remaining pressure in the system.

Step 2: Replace the Filter
- Twist and remove the filter (PCT or RO) that you want to replace.
- Remove the rubber ring from the old filter and attach it to the new one.
- Insert the new filter into the machine and twist it into the locked position.

Step 3: Flush the New Filter
- Turn on the water inlet valve.
- Keep the faucet open to flush the new filter.
- Let water run for about 1–3 minutes (approximately 3–5 gallons) to fully flush the system.

Step 4: Reset the Filter Life
- Locate the "R" button at the bottom of the machine.
- Press the "R" button once — the screen will display the filter type (PCT or RO).
- If the displayed filter is not the one you replaced, press the "R" button again to switch to the correct filter.
- Once the correct filter is selected, press and hold the "R" button for 3–5 seconds until you hear a confirmation beep.
- The machine will reset the filter life on the display.

AR2800P 淨水器濾芯更換及重置操作說明

（PCT / RO 濾芯）

步驟 1：更換前準備
- 關閉進水閥門。
- 打開淨水龍頭，釋放系統內殘留的水壓。

步驟 2：更換濾芯
- 將需要更換的濾芯（PCT 或 RO）旋轉取出。
- 從舊濾芯上取下橡膠圈，並安裝到新的濾芯上。
- 將新濾芯插入機器，按照正確方向旋轉，直到鎖定到位。

步驟 3：沖洗新濾芯
- 打開進水閥門，恢復供水。
- 保持淨水龍頭開啟，沖洗新更換的濾芯。
- 持續放水約 1－3 分鐘（約 3－5 加侖），確保新濾芯及系統內部充分沖洗。

步驟 4：重置濾芯使用壽命
- 找到機器底部的 「R」重置按鈕。
- 短按一次「R」按鈕，螢幕將顯示目前選擇的濾芯類型（PCT 或 RO）。
- 如果螢幕顯示的不是本次更換的濾芯，請再次短按「R」按鈕，切換至正確的濾芯類型。
- 確認選擇正確後，長按「R」按鈕 3－5 秒，直到聽到確認提示音。
- 機器將自動重置該濾芯的使用壽命，螢幕上的濾芯壽命顯示也會隨之更新。